


## Parts needed to mount the PUSZ-LIN-MR fastener



## **Tools needed for mounting:**


- Allen wrench
- drill
- pliers

NOTE! A list of products corresponding with the selected accessories is available at www.klusdesign.eu


www.klusdesign.eu 1




**1.** Drill holes with a diameter of 4mm to 8mm in the back of the extrusion. One hole per fastener.







 $\bf 3.$  Run the cable through the small washer (D) and put the sleeve (C) on the entire assembly. Tighten the sleeve on the arm with thread to stop the fastener from moving




**4.** Attach the power connector (E) to the cable end.



5. Run a steel cable through the clamp (F) twice. Then squeeze the clamp with e.g. pliers to stop the steel cable from moving.




**6.** Insert the end of the steel cable into the power connector (E) and squeeze it by tightening the terminals of the power connector with the Allen wrench.



www.klusdesign.eu 2







www.klusdesign.eu 3